

# Powerfloat User Guide.



## **Repack instructions.**

1. When packing for the first time or after use lie the vest flat and remove all the air using the relief valve on the oral inflation tube.
2. Starting at the top Constantine in the vest and secure in place with the Velcro.
3. Fold both sides in at 45 degree's as shown
4. Starting on the automatic inflation side Constantine in the vest so the inflator and Co2 canister are on top, the toggle can be hung outside for manual inflation if desired.
5. Then Constantine in the oral inflation side so the tube is on top, this allows you to remove any excess air by depressing the relief valve on top of the tube.
6. Working from the top middle of the vest recheck the Velcro is secured evenly and if needed adjust. The vest is then ready to be installed onto you PPG unit.